

ADEMCO VISTA 15P/20P

Check for open zones by pressing the star (*) key. The keypad will display all open zones.

STAY ARMING: Make sure the **ready** light is on. Enter your code and press the 3 key (STAY). This will automatically bypass any motion detectors.

AWAY ARMING: Make sure the **ready** light is on. Enter your code and press the 2 key (AWAY).

INSTANT ARMING: Make sure the **ready** light is on. Enter your code and press the 7 key (INSTANT). This will automatically bypass any motion detectors and remove the entry/exit delay from the entry/exit doors. This mode of arming should only be used when staying in the house since there is no longer any entry delay.

MAXIMUM ARMING: Enter your code and press the 4 key (MAX). This mode of arming would be used in certain circumstances such as vacation or other extended periods away from the premise. This will arm everything including motion detectors and removes the entry/exit delay from the entry/exit doors.

BYPASSING ZONES: Enter your code and press 6 (BYPASS) then enter the two-digit zone you want bypassed (zone 3 would be 03) followed by the star key.

DISARMING: Enter your code and press 1 (OFF)

CHIME: You can activate the Chime feature by entering your code then pressing 9 (CHIME).

PROGRAMMING CODES: To change your **master code**, follow this procedure. Enter your current master code + 8 + 02 + new (4 digit) master code + new master code. To program an access code, enter your current master code + 8 user number (number ranging from 04-32) + 4-digit access code.

The default master code is 1234.