

Caddx 8900/8900DL Basic Information

Zones	6 Hardwired
Wireless	No
Battery	12 volt rechargeable Gel-Cell inside main panel AC Transformer is 16.5 volts, screwed into outlet in house
Panic Buttons	Police Panic * and # Fire Panic 1 and 3 Medical Panic 4 and 6
Downloadable	Only the 8900DL version is downloadable, customer must be home to activate
Arm	4 digit code (MUST have green READY light)
Disarm	4-digit code (if incorrect code is entered wait 2 seconds and try again)
Instant Arm	Press * after arming (INSTANT light will turn on)
Quick-Arm	Enter Quick Arm Digit (If enabled by Installer)
Bypass	* + Zone (1 to 6) + *
Alarm Memory	There is no alarm memory
Smoke Reset	4 digit code to silence alarm, # to reset Smoke (If this does NOT reset smoke detector set for service, smoke is bad)
Door Chimes	Enter 1st digit of Master Code, keypad beeps and chime is enabled/disabled

Caddx 8900/8900DL User Codes

Master Code	User 1
Secondary Codes	User 2 to 14
Hostage Code	User 15
Add Code	1. Press * 2. Enter User (1 to 15) then # 3. Enter Master Code 4. Press * 5. Enter User (1 to 15) again then # 6. Enter New User Code 7. Press * 8. Enter User (1 to 15) again then # <i>Example: to add User 2 as 1234 enter * 2 # Master Code * 2 # 1234 * 2 #</i>
Erase Code	1. Press * 2. Enter User (2 to 15) then # 3. Enter Master Code 4. Press * 5. Enter User (2 to 15) again then # 6. Enter Master Code again 7. Press * 8. Enter User (2 to 15) again then # <i>Example: to erase User 2 enter * 2 # Master Code * 2 # Master Code * 2 #</i>

Caddx 8900/8900DL Trouble Display

POWER Light indicates trouble	
POWER ON	System operating normally
POWER OFF	AC Failure
POWER Flashing	Backup Battery Low
Smoke Reset	Enter 4 digit code to silence alarm, # to reset Smoke (If smoke detector still sounds power down system, set for service)
System can be armed with trouble, however keypad will beep at every command, enter code again to continue	