

HAI Omni Cheat Sheet

If Keypad says "Had Trouble" press * to clear the message
If Keypad says "Has Trouble" contact Service Department
To clear "Battery Had Trouble" after replacing battery, press 6 (Setup), then 4 (Test) then Press * to return to main screen

CONSOLE DISPLAYS

All OmniPro II commands are menu based.
For the main menu, press **#** :

1=CONTROL	2=SECURITY
3=BUTTON	4=ALL ↓

Press ↓ for the next display:

5=TEMP	6=STATUS
7=EVENTS	8=MESSAGE ⇅

9=SETUP ↑

Press ↓ when entering a unit, zone, button, temperature, code, or message to scroll through the list of names.

Press ↓ to advance to the next item.

Press ↑ to go back to the previous item.

CONSOLE FUNCTIONS

*	Used to cancel and return the display to the previous menu.
#	Used to enter / confirm a selection or to display a menu.
1 Beep	Your command has been properly entered.
2 Beeps	Trouble Beeps - Press * to silence beeper.
3 Beeps	Error! Please reenter command. Press * to start over.
Beeper on Continuously	An alarm has occurred.

SECURITY

Disarm System & Silence Alarms	OFF CODE
Arm Security	AWAY OR NIGHT OR DAY CODE <small>Be sure display reads "SYSTEM OK"</small>
Arm Security to Vacation Mode	2 4 CODE
Bypass a Zone	2 8 Zone # CODE
Restore all Zones	2 9 0 #
Quick Arm	AWAY OR NIGHT OR DAY TWICE
Review Events	7 MASTER CODE ↑/↓
Reset Smoke Detectors	Arm or Quick Arm
Emergency Keys	1 + 3 = Police Emergency 4 + 6 = Fire Emergency 7 + 9 = Auxiliary Emergency <small>Alarm is activated with the simultaneous depression of two keys for 1 second.</small>

SETUP ITEMS

Set Time (7:30 pm)	9 MASTER CODE 2 7 3 0 ↓
Enter Date (April 15, 00)	0 4 1 5 0 0
Set New Codes	9 MASTER CODE 1 Press ↓ OR ↑ to display each item.
Set Phone Options	9 MASTER CODE 4 To change an item, enter your choice, then press # .
Set Delays and Arming Options	9 MASTER CODE 5

Monitoring Station	Service Department
24/7	M-F 8-5
1-866-539-8807	512-302-1181